



Pre Trip Checklist for Air Force One

For any questions, please call 800-543-3626

- 1.** Clean both the female and male connectors on back of coach, and on front of towed vehicle.

- 2.** Clean both the female and male connectors on Air jumper hose, connect hose ensuring both connections are fully seated

- 3.** Run the coach to air up the coach air brake system

- 4.** Apply brake pedal in the coach while assistant is watching the brake pedal in towed. Apply 1/2 - 3/4 and full brake ensuring proper operation

- 5.** Finish by applying and holding full brake for 5-10 seconds

- 6.** Pull break away pin to ensure brake pedal in towed vehicle applies

- 7.** Reinstall break away pin

- 8.** Repeat Step 5

- 9.** The Air Force One brake system is ready for towing